




08/942,347






1/. .


REMOTE INTERFACE SERIAL PROTOCOL MESSAGE FORMATS







RESPONSE:



RESPONSE:








FIG. 3











F/G. 5


















08/942,347






FIG. 10B






FIG. 11









FIG. 12C






FIG. 13B

08/942,34/







FIG. 14



08/942,347



F/G. 16



F16.11

Maestro Recovery Manager – Fans erver View Help NF 9000 B System Status			_		$\frac{\parallel}{\parallel}$		
⊻iew <u>H</u> elp NF 9000 □ System Status							
NF 9000							
System Status	Location /	Fan Speed	d Speed Control	Fault Indicator	LED Fault	Low speed f	fault threshold speed
) System Board	1 4740) high	NO	YES	4740	
Power Supplies		2 5160			YES		
Temperatures		3 4260			YES		
		4 8520			YES		
System Board		5 9540			по		
) & 		6 480			0		
) Canister A	1 4740) high	NO	ПО	4740	
		2 5160			0		
Canister C) Canister B	1 4740) high	NO	0	4740	
Canister D		2 5160			0 0		
⊕ □ Processors) Canister C	1 4740) high	NO	no OL	4740	
—⇒==>1/0 Canisters		2 5160			on O		
Serial Numbers) Canister D	1 4740) high	NO	no	4740	
Revisions 994		2 5160			00		
	Refresh	Help				•	
096	786						All I
For Help, press F1							
			01 01				N

F16.18




FIG. 15